

<b>SCOTTS TRIPLE CLAMP APPLICATIONS</b>			<i>Position Relative to stock</i>		<i>Handlebar Position 1</i>	<i>Handlebar Position 2</i>
<i>BIKE</i>	<i>YEAR</i>	<i>PART #</i>				
<b>HONDA</b>						
CR 80 / 80 expert / 85 <i>solid mounts</i>	1996-07	7077	+7mm		90 40 30	90 40 36
CR 125	1999-07	7057R	call us		106 40 31	106 40 37
CR 250	1996-07	7057R	call us		106 40 31	106 40 37
CRF 150R <i>solid mount only</i>	2007-10	7077	+7mm		90 40 30	90 40 36
CRF 250R	2004-07	7057R	same		106 40 31	106 40 37
CRF 250R	2008-09	9254R	+3mm		106 40 31	106 40 37
CRF 250R	2010-12	9257R	+3mm		106 40 31	106 40 37
CRF 250X	2004-12	7057R-01	same		106 40 31	106 40 37
CRF 450R	2002-07	7057R	same		106 40 31	106 40 37
CRF 450R	2008	9254R	+3mm		106 40 31	106 40 37
CRF 450R	2009-12	9257R	+3mm		106 40 31	106 40 37
CRF 450X	2005-07	7057R-01	same		106 40 31	106 40 37
CRF 450X	2008-12	9254R-01	+3mm		106 40 31	106 40 37
CR 250 / 450R <i>upper &amp; lower set (22)</i>	1996-04	7078R-22	same		106 40 31	106 40 37
CR/CRF/CRF-X <i>upper &amp; lower set (22)</i>	2005-07	7079R-22	same		106 40 31	106 40 37
CR 500 ( <i>requires 7072-1 bushing</i> )	1997-01	7057R	+6mm		106 40 31	106 40 37
XR 250 <i>solid mount only</i>	1996-04	7063	+12mm		100 40 23	100 40 29
XR 400 <i>solid mount only</i>	1996-04	7058	+12mm		100 40 23	100 40 29
XR 600 <i>solid mount only</i>	1988-01	7058	+12mm		100 40 23	100 40 29
XR 650R <i>solid mount only</i>	2000-07	7074	+12mm		100 40 23	100 40 29
XR 650L <i>solid mount (requires special drilling)</i>	1998-12	7058	+12mm		100 40 23	100 40 29

Highlighted areas indicate the position that comes as standard on our triple clamps.  
Columns marked "call us" means there are multiple possibilities listed.

<b>SCOTTS TRIPLE CLAMP APPLICATIONS</b>			<i>Position Relative to stock</i>		<i>Handlebar Position 1</i>	<i>Handlebar Position 2</i>
<i>BIKE</i>	<i>YEAR</i>	<i>PART #</i>				
<b>HUSQVARNA</b>						
SMR 450 / 510	2006-07	9242R-SUB			SUB MNT	10012-P3
TC 250	2008-09	9258R	+3mm		100 40 29	100 40 35
TC 250	2010-11	9261R-50 & SUB	+3mm		SUB MNT	10012-P3
TC 450 / 510	2006-07	9219R-SUB	+11mm		SUB MNT	09311-P4
TC 450 / 510	2008-09	9258R	+3mm		100 40 29	100 40 35
TC 450 / 510	2010	9261R-50 & SUB	+3mm		SUB MNT	10012-P3
TC 449 / 511	2011	9261R-31 & SUB	+3mm		SUB MNT	10012-P3
TE 250	2001-07	1006R	+11mm		90 40 30	90 40 36
TE 250	2008-09	9219R-SUB	+11mm		SUB MNT	09311-P4
TE 250	2010-11	9261R-50 & SUB	+3mm		SUB MNT	10012-P3
TE 310	2008-09	9258R	+3mm		100 40 29	100 40 35
TE 310	2010-11	9261R-50 & SUB	+3mm		100 40 29	100 40 35
TE 310	2012					
TE 450 / 510	2001-05	1006R	+11mm		90 40 30	90 40 36
TE 450 / 510	2006-07	9219R-SUB	+15mm		SUB MNT	09311-P4
TE 450 / 510	2008-09	9258R	+3mm		100 40 29	100 40 35
TE 450 / 510	2010	9261R-50 & SUB	+3mm		SUB MNT	10012-P3
TE 449 / 511	2011	9261R-31 & SUB	+3mm		SUB MNT	10012-P3
TXC 250	2008-09	9258R	+3mm		100 40 29	100 40 35
TXC 250	2010-11	9261R-50 & SUB	+3mm		SUB MNT	10012-P3
TXC 310	2012					
TXC 450 / 510	2008-09	9258R	+3mm		100 40 29	100 40 35
TXC 450 / 510	2010	9261R-50 & SUB	+3mm		SUB MNT	10012-P3
TXC 449 / 511	2011	9261R-31 & SUB	+3mm		SUB MNT	10012-P3
WR 125	2001-08	1006R	+11mm		90 40 30	90 40 36
WR 150	2011	9219R-SUB	+11mm		SUB MNT	09311-P4
WR 250	2001-08	1006R	+11mm		90 40 30	90 40 36
WR 250 /300	2009-10	9219R-SUB	+11mm		SUB MNT	09311-P4
WR 250 /300	2011	9261R-50 & SUB	+3mm		SUB MNT	10012-P3

Highlighted areas indicate the position that comes as standard on our triple clamps.  
Columns marked "call us" means there are multiple possibilities listed.

<b>SCOTTS TRIPLE CLAMP APPLICATIONS</b>			<i>Position Relative to stock</i>		<i>Handlebar Position 1</i>	<i>Handlebar Position 2</i>
<i>BIKE</i>	<i>YEAR</i>	<i>PART #</i>				
<b>HUSABERG</b>						
All models	2003-06	9221R	same as pos#3		90 40 34	90 40 41
All models	2007-08	NA / stock is billet	X		X	X
All models	2009	9222R	same as pos#3		90 40 34	90 40 41
All models	2010-11	9259R	same as pos#3		90 40 34	90 40 41
<b>GAS GAS</b>						
MC/XC/EC 50mm conv forks	1997-00	6050	+12mm		100 40 26	100 40 32
MC/XC/EC 43/45mm inverted forks	2001-03	6043R	+8mm		100 40 35	100 40 40
MC/XC/EC 43/45mm inverted forks	2004-08	6043R	+8mm		100 40 35	100 40 40
MC/XC/EC 43/45mm inverted forks	2009-2011	6043R	same as pos#2		100 40 35	100 40 40
<b>KAWASAKI</b>						
KDX 200 / 220 <i>solid mounts</i>	1995-07	5622	+4mm		90 40 30	90 40 36
KLX 400R & KLX400SR <i>solid mnts</i>	2003-04	2006	+9mm		100 40 26	100 40 32
KLX 450R	2008-09	5634R	+9mm		100 40 29	100 40 35
KX 80 / 85 / 100 <i>solid mounts</i>	1998-11	5628	+14mm		90 40 34	90 40 41
KX 125 / 250 <i>solid mounts</i>	1996-98	5612	+12mm		90 40 34	90 40 41
KX 125 / 250	1999-01	5616R				
KX 125 / 250 <i>lower clamp</i>	1998-01	5617-L	lower		Lower	Lower
KX 125 / 250 <i>solid mounts</i>	2002	5627	+8mm		90 40 34	90 40 41
KX 125 / 250 <i>solid mounts</i>	2003-07	5633	+8mm		90 40 34	90 40 41
KX 500 <i>rubber mounts</i>	1997-04	5619R	+8mm		90 40 30	90 40 34
KX 250F <i>solid mounts</i>	2004-05	5633	+8mm		90 40 34	90 40 41
KX 250F <i>rubber mounts</i>	2006-08	9223R	+3mm		100 40 29	100 40 35
KX 250F <i>rubber mounts</i>	2009-12	9256R	+2mm		100 40 29	100 40 35
KX 450F <i>rubber mounts</i>	2006-08	5634R	+6mm		100 40 29	100 40 35
KX 450F <i>rubber mounts</i>	2009-12	9255R	+5mm		100 40 29	100 40 35

Highlighted areas indicate the position that comes as standard on our triple clamps.  
Columns marked "call us" means there are multiple possibilities listed.

<b>SCOTTS TRIPLE CLAMP APPLICATIONS</b>			<b>Position</b>		<b>Handlebar</b>	<b>Handlebar</b>
<b>BIKE</b>	<b>YEAR</b>	<b>PART #</b>	<b>Relative to stock</b>		<b>Position 1</b>	<b>Position 2</b>
<b>KTM 2-STROKES</b>						
125 / 200 "STD" solid mounts	1998-99	3008	+2mm		90 40 30	90 40 36
125 / 200 Exc Mxc Xcw	2000-07	3009R	same as pos#3		90 40 34	90 40 41
125 / 200 Exc Mxc Xcw Upper & lower solid	2003-07	3010-18	same as pos#3		90 40 34	90 40 41
125 / 200 Sx	2000-02	3009R	same as pos#3		90 40 34	90 40 41
125 / 200 Sx Upper & lower solid set	2002	3010-18	same as pos#3		90 40 34	90 40 41
125 / 200 Sx upper only	2003-04	N/A				
125 / 200 Sx Upper & lower solid set	2003-04	3010-18	same as pos#3		90 40 34	90 40 41
125 / 144 / 200 Sx Xc	2005-07	9222R	same as pos#3		90 40 34	90 40 41
125 / 144 / 150 / 200 Sx Xc Xcw	2008-09	9222R	same as pos#3		90 40 34	90 40 41
125 Sx	2012	9222R	same as pos#3		90 40 34	90 40 41
150 Sx Xc / 200 Xcw	2010-12	9259R	same as pos#3		90 40 34	90 40 41
250 Exc Mxc Xcw	2000-07	3009R	same as pos#3		90 40 34	90 40 41
250 Exc Mxc Xcw Upper & lower solid set	2003-07	3010-18	same as pos#3		90 40 34	90 40 41
250 Sx	2000-02	3009R	same as pos#3		90 40 34	90 40 41
250 Sx Upper & lower set	2002	3010-18	same as pos#3		90 40 34	90 40 41
250 Sx upper only	2003	N/A				
250 Sx Upper & lower solid set (18mm)	2003	3010-18	same as pos#3		90 40 34	90 40 41
250 Sx	2004	3009R	same as pos#3		90 40 34	90 40 41
250 Sx Upper & lower solid set	2004	3010-18	same as pos#3		90 40 34	90 40 41
250 Sx Xc	2005-07	9222R	same as pos#3		90 40 34	90 40 41
250 Sx Xc	2008-09	9222R	same as pos#3		90 40 34	90 40 41
250 Xcw	2008-10	9222R	same as pos#3		90 40 34	90 40 41
250 Sx Xc Xcw	2010-12	9259R	same as pos#3		90 40 34	90 40 41
300 Exc Mxc Xcw	2000-07	3009R	same as pos#3		90 40 34	90 40 41
300 Exc Mxc Xcw Upper & lower solid set	2003-07	3010-18	same as pos#3		90 40 34	90 40 41
300 Xc	2006-07	9222R	same as pos#3		90 40 34	90 40 41
300 Xc Xcw	2008-09	9222R	same as pos#3		90 40 34	90 40 41
300 Xcw	2010-11	9222R	same as pos#3		90 40 34	90 40 41
300 Xc	2010-12	9259R	same as pos#3		90 40 34	90 40 41
300 Xcw	2012	9259R	same as pos#3		90 40 34	90 40 41
<b>Ktm continued on next page</b>						

Highlighted areas indicate the position that comes as standard on our triple clamps.  
Columns marked "call us" means there are multiple possibilities listed.

<b>SCOTTS TRIPLE CLAMP APPLICATIONS</b>			<b>Position</b>		<b>Handlebar</b>	<b>Handlebar</b>
<b>BIKE</b>	<b>YEAR</b>	<b>PART #</b>	<b>Relative to stock</b>		<b>Position 1</b>	<b>Position 2</b>
<b>KTM 4-STROKES</b>						
250 EXC MXC	2002-09	3009R	same as pos#3		90 40 34	90 40 41
250 EXC-F	2010-11	9222R	same as pos#3		90 40 34	90 40 41
250 EXC-F	2012	9262R	same as pos#3		90 40 34	90 40 41
250 SXF	2005-09	9222R	same as pos#3		90 40 34	90 40 41
250 SXF	2010-12	9259R	same as pos#3		90 40 34	90 40 41
250 XCF	2007-11	9222R	same as pos#3		90 40 34	90 40 41
250 XCF	2012	9259R	same as pos#3		90 40 34	90 40 41
250 XCF-w	2007	3009R	same as pos#3		90 40 34	90 40 41
250 XCF-w	2008-11	9222R	same as pos#3		90 40 34	90 40 41
250 XCF-w	2012	9262R	same as pos#3		90 40 34	90 40 41
350 EXC XCF-w	2012	9262R	same as pos#3		90 40 34	90 40 41
350 SXF XCF	2011-12	9259R	same as pos#3		90 40 34	90 40 41
400 Sx	2000-02	3009R	same as pos#3		90 40 34	90 40 41
400 Sx <i>Upper &amp; lower solid set</i>	2002	3010-18	same as pos#3		90 40 34	90 40 41
400 Exc Mxc	2000-05	3009R	same as pos#3		90 40 34	90 40 41
400 Exc Mxc <i>Upper &amp; lower solid set</i>	2004-05	3010-18	same as pos#3		90 40 34	90 40 41
400 Exc Xcw	2006-07	3009R	same as pos#3		90 40 34	90 40 41
400 Xc	2006-07	9222R	same as pos#3		90 40 34	90 40 41
400 Xcw	2007-10	9222R	same as pos#3		90 40 34	90 40 41
450 Exc Mxc Xcw <i>upper only</i>	2003-07	3009R	same as pos#3		90 40 34	90 40 41
450 Exc Mxc Xcw <i>Upper &amp; lower solid set</i>	2003-07	3010-18	same as pos#3		90 40 34	90 40 41
450 Exc-R	2008	3009R	same as pos#3		90 40 34	90 40 41
450 Exc <i>(USA bikes only / Non-USA are 3009R)</i>	2009-11	9222R	same as pos#3		90 40 34	90 40 41
450 SX <i>upper only</i>	2003-04	3009R	same as pos#3		90 40 34	90 40 41
450 SX <i>Upper &amp; lower solid set</i>	2003-04	3010-18	same as pos#3		90 40 34	90 40 41
450 SXF	2005-09	9222R	same as pos#3		90 40 34	90 40 41
450 SXF	2010-12	9259R	same as pos#3		90 40 34	90 40 41
450 SMC / SMR	2004	3009R	same as pos#3		90 40 34	90 40 41
450 SMC / SMR	2005-06	9222R	same as pos#3		90 40 34	90 40 41
450 XC	2006-07	9222R	same as pos#3		90 40 34	90 40 41
450 XCW	2007	3009R	same as pos#3		90 40 34	90 40 41
450 XCW	2008-11	9222R	same as pos#3		90 40 34	90 40 41
450 XCW	2012	9262R	same as pos#3		90 40 34	90 40 41
<b>Ktm continued on next page</b>						

Highlighted areas indicate the position that comes as standard on our triple clamps.  
Columns marked "call us" means there are multiple possibilities listed.

SCOTTS TRIPLE CLAMP APPLICATIONS			Position		Handlebar	Handlebar
BIKE	YEAR	PART #	Relative to stock		Position 1	Position 2
<b>KTM 4-STROKES (Continued)</b>						
500 Exc Xcw	2012	9262R	same as pos#3		90 40 34	90 40 41
505 SxF XcF	2007-09	9222R	same as pos#3		90 40 34	90 40 41
520 Exc Mxc Sx	2000-02	3009R	same as pos#3		90 40 34	90 40 41
520 Sx <i>Upper &amp; lower solid set</i>	2002	3010-18	same as pos#3		90 40 34	90 40 41
525 Exc Mxc Xcw <i>upper only</i>	2003-07	3009R	same as pos#3		90 40 34	90 40 41
525 Exc Mxc Xcw <i>Upper &amp; lower solid set</i>	2003-07	3010-18	same as pos#3		90 40 34	90 40 41
525 Xc	2006	3009R	same as pos#3		90 40 34	90 40 41
525 Xc	2007	9222R	same as pos#3		90 40 34	90 40 41
525 Sx <i>upper only</i>	2003-04	3009R	same as pos#3		90 40 34	90 40 41
525 Sx <i>Upper &amp; lower solid set</i>	2003-04	3010-18	same as pos#3		90 40 34	90 40 41
525 Sx	2005-07	9222R	same as pos#3		90 40 34	90 40 41
525 Smr	2005	9222R	same as pos#3		90 40 34	90 40 41
530 Exc-R	2008	3009R	same as pos#3		90 40 34	90 40 41
530 Exc <i>(USA bikes only / Non-USA are 3009R)</i>	2009-11	9222R	same as pos#3		90 40 34	90 40 41
530 Xc Xcw	2008-11	9222R	same as pos#3		90 40 34	90 40 41
560 Smr	2006-07	9222R	same as pos#3		90 40 34	90 40 41
640 LC4 Adventure <i>rubber mounts</i>	2005-08	3012R-18 (SUB)	+12mm		Sub Mount	1006P3
950/990 Adventure <i>rubber mounts</i>	2003-12	3012R-18 (SUB)	+21mm		Sub Mount	1006P3
950 Super Enduro <i>rubber mounts</i>	2007-10	3012R-20 (SUB)	+21mm		Sub Mount	1006P3
950 SM	2005-08	3012R-28 (SUB)	+18mm		Sub Mount	1006P3
950 SMR	2008-09	3012R-27 (SUB)	+18mm		Sub Mount	1006P3
<b>SUZUKI</b>						
RM 80 / 85 <i>(solid mounts)</i>	2002-11	2009			90 40 34	90 40 41
RM 125 <i>(solid mounts)</i>	2005-08	2010	stock		100 40 35	100 40 40
RM 250 <i>(solid mounts)</i>	1996-98	2001	+1mm		100 40 29	100 40 29
RM 250 <i>(solid mounts)</i>	2004-08	2010	stock		100 40 35	100 40 40
RM-Z 250 <i>(solid mounts)</i>	2004-06	5633 / 5633R	+2mm		90 40 34	90 40 41
RM-Z 250	2007-12	2011 / 2011R	stock		100 40 35	100 40 40
RM-Z 450	2005-09	2011 / 2011R	stock		100 40 35	100 40 40
RM-Z 450	2010-12	2011 / 2011R	stock		100 40 35	100 40 40
DRZ 400 & "S" models <i>(solid mounts)</i>	2000-08	2006	+9mm		100 40 26	100 40 32

Highlighted areas indicate the position that comes as standard on our triple clamps.  
Columns marked "call us" means there are multiple possibilities listed.

SCOTTS TRIPLE CLAMP APPLICATIONS			Position		Handlebar	Handlebar
BIKE	YEAR	PART #	Relative to stock		Position 1	Position 2
<b>YAMAHA</b>						
YZ 80 / 85 <i>solid mounts</i>	1993-10	9209	+6mm		90 40 26	90 40 32
YZ 125	2000-03	9204R	call us		100 40 35	100 40 40
YZ 125 <i>Upper &amp; lower set solid mount</i>	2003	9204-22	stock		100 40 35	100 40 40
YZ 125	2004-05	9216R	stock		100 40 35	100 40 40
YZ 125	2006-12	9218R	stock		100 40 35	100 40 40
YZ 250	2000-03	9204R	call us		100 40 35	100 40 40
YZ 250 <i>Upper &amp; lower set solid mount</i>	2003	9204-22	stock		100 40 35	100 40 40
YZ 250	2004-05	9216R	stock		100 40 35	100 40 40
YZ 250	2006-12	9218R	stock		100 40 35	100 40 40
YZF 250	2001-03	9204R	call us		100 40 35	100 40 40
YZF 250	2004-05	9216R	stock		100 40 35	100 40 40
YZF 250	2006-08	9218R	stock		100 40 35	100 40 40
YZF 250	2009	9218R	+6mm		100 40 35	100 40 40
YZF 250	2010-11	new?				
YZF 426	2000-02	9204R	call us		100 40 35	100 40 40
YZF 450	2003	9204R	stock		100 40 35	100 40 40
YZF 450 <i>Upper &amp; lower set solid mount</i>	2003	9204-22	stock		100 40 35	100 40 40
YZF 450	2004-05	9216R	stock		100 40 35	100 40 40
YZF 450	2006-08	9218R	stock		100 40 35	100 40 40
YZF 450	2009	9218R	+6mm		100 40 35	100 40 40
YZF 450	2010-12	9260R	+6mm		100 40 35	100 40 40
YZ / YZF <i>Lower clamp only</i>	1996-02	9208-L			Lower	Lower
WR 250F	2001-04	9204R	stock		100 40 35	100 40 40
WR 250F	2005-12	9216R	stock		100 40 35	100 40 40
WR 400F	1998-99	9204R	+19mm		100 40 35	100 40 40
WR 426F	2000-02	9204R	+9mm		100 40 35	100 40 40
WR 450F	2003-04	9204R	stock		100 40 35	100 40 40
WR 450F	2005-10	9216R	stock		100 40 35	100 40 40
WR 450F	2012					
WR 250F / WR450F <i>upper and lower set</i>	2003-04	9204-22	stock		100 40 35	100 40 40
WR <i>Lower clamp only</i>	1996-02	9208-L	DNA		Lower	Lower

Highlighted areas indicate the position that comes as standard on our triple clamps.  
Columns marked "call us" means there are multiple possibilities listed.

12/15/2011