



2625 Honolulu Ave • Montrose, CA 91020 • 818 248-6747 • Fax: 818 248-4529
 www.scottsonline.com • e-mail: sales@scottsonline.com

Installation guidelines for the multiple position SUB MOUNTS:

1. Review the photos before starting, so you have an idea of the goal we are trying to achieve.
2. Some Triple clamps have one set of holes, some have 2 sets of holes, install the lower third of the SUB mount, into the "rear" set of holes in your Triple Clamp and torque the bolts/nuts or studs to the specified settings.
3. Once the SUB base is installed you'll notice the elliptical boss machined into the bottom of the lower perches which allows you to reverse the lower perches to achieve a farther forward handlebar position.
4. Match both of the lower perches to the position you prefer to ride with, and both them to the SUB mount base once you have the elliptical bosses engaged properly into the SUB mount base.
5. You can reverse the position by simply spinning the lower perches 180 degrees. You'll notice we have 3 dimples in the lower perches to assist in lining up the perches. Be sure to tighten all bolts upon the final installation.
6. If you have any questions please call us for assistance. 818 248-6747.



Bottom third ready to mount



SUB base mounted to triple clamp



Elliptical bosses on lower perches



Next bolt the lower perches to the base



Finally the upper perches bolted to lowers



This shows position 1 closest to rider



Turn the lower perches around for position 2

